

REPLACING ATOM SADDLE

Tools required

4mm Allen Key
2.5mm Allen Key
Cross Head Screw Driver
Circlip Pliers

1.1 SADDLE FORE & AFT ADJUSTMENT

Loosen 4mm Allen key grub screw, SS7, at the rear of the Seat Mount, SS12, and move the Seat Block fore or aft as required then tighten to hold in position.



1.2 REMOVAL OF SADDLE

1. Loosen 5mm Allen key bolt on the right hand side of the Saddle Clamp, SS2, until the rails of the saddle can be removed.



2. Twist the clamp anti-clockwise to help release the seat rails.



3. Reverse the process to fit a replacement saddle **N.B. The 5mm Allen key bolt will need to be tightened enough to prevent the saddle tipping fore and aft.**