

ATOM SERVICING

HANDLEBAR LOCK LEVER

Tools required

2.5mm Allen Key

Circlip Pliers

1. Remove the 2.5mm Allen key, LL6, from the centre of the Lock Lever Handle, LL3.



2. Remove the Cap, LL5, Spring, LL4, and Handle.



3. Remove the circlip, LL2, using a set of circlips pliers.



4. Replace the handle and unthread/unwind the threaded section of the lock lever, LL7.



5. Reverse to replace – **N.B. the circlip is there to stop the Lock Lever coming out of the frame of the bike. (The Handlebar, LL7, & Seat Lock, LL1, Lever Thread are different lengths)**